

STEP: 02 INSTALL WP713
TO THE FRAME

STEP: 03 INSTALL HOOK
TO THE LCD

STEP: 01 INSTALL THE BASE

FRONT

